



I Supplies for one-piece QUILT-WRAP

Bonny Brewer © 2010

1. ABS 1-1/2 inch (inside) diameter drain pipe or foam pipe insulation (both are about 2 inches in outside diameter):



2. Fabric or sheeting larger than the quilt:



3. Cotton twill tape (1/4 to 1/2 inch), shoe laces, or other fabric ties:


 24 inches long for the end ties (need 2)

 36 inches long for the center ties (need 1 or more depending on the width of the quilt-- approximately 15-18 inches between ties)

4. A short piece (3 inches) of hook-and-loop tape (velcro).




II Finishing the edges and preparing the sleeve




1. From the wrong side of the fabric, stitch 1/4 inch double fold (or serge raw edge) along both sides of the quilt-wrap.

4. Stitch across the end of the sleeve approximately 3 inches from the edge. Reinforce with a second line of stitching.




5. Finish bottom edge with a 1/4 inch stitched, double fold (or serge the raw edge or take advantage of a finished selvedge).

III Attaching the ties and label and inserting the tube



IV Packaging the quilt



9. Place quilt face down on inside of wrap with top closest to the tube. Insert the hanging stick in its sleeve.

10. Roll up quilt snugly inside the wrap and secure with the ties.

